

Serenity Barrel Sauna Assembly Instructions

Harvia M3 Wood Stove Installation (Chimney out the top) (Optional)



Remove all protective film from stainless steel parts and the plastic wrap from stove pipe pieces before installation.



Fasten the stove handle onto the stove door With the screws provided.



Install floor heat shield against back wall centered between the benches.



Place the rear wall heat shield and secure with 6 - 1 ½" (38mm) screws through the drilled holes.

Manufactured by:

Serenity Barrel Sauna Assembly Instructions

Harvia M3 Wood Stove Installation (Chimney out the top) (Optional)



Bring in the stove and ensure it is centered between the benches with the chimney hole 8" (203mm) from the rear heat shield.



On the top of the sauna, measure 12" (305mm) from the end of staves.

From the mark, make an 8" (203mm) circle.



Cut the circle out with a jigsaw.



Place the long chimney piece onto the stove.

Manufactured by:

Serenity Barrel Sauna Assembly Instructions

Harvia M3 Wood Stove Installation (Chimney out the top) (Optional)



Place the first thick insulated chimney pipe on top of the first pipe and put it through the hole in the roof.



On the top of the sauna, pull the boot over the pipe, mark the outline of the boot.



Lift the boot out of the way and apply the included roof sealer on the inside of the outline.



Pull the boot back down and secure with the included self sealing roofing screws 2-3" (51mm to (76mm)) apart.

Manufactured by:

Serenity Barrel Sauna Assembly Instructions

Harvia M3 Wood Stove Installation (Chimney out the top) (Optional)



Place the hose clamp over the boot and tighten the screw.



Place the 2nd insulated chimney piece over the first.



Attach the support strap around the 2 chimney pipes and tighten up.



Insert the short chimney piece into the thick chimney piece, followed by the cap piece.

Manufactured by:



tel: 888-923-9813 | info@leisurecraft.com | web: www.leisurecraft.com

Serenity Barrel Sauna Assembly Instructions

Harvia M3 Wood Stove Installation (Chimney out the top) (Optional)



Install the 2 halves of the thin metal sheeting around the chimney on the inside to cover the hole.



Below the bench support on the back wall, mark the vent hole position.



Drill out with a 2" (51mm) hole saw.

Only go half way through to prevent splintering and drill the remainder from the other side of wall.



Using 1 ½" (38mm) screws, screw on the vent cover.

(note that the vent guard only goes on the outside.)

Manufactured by:

Serenity Barrel Sauna Assembly Instructions

Harvia M3 Wood Stove Installation (Chimney out the top) (Optional)



High on the front wall, repeat this process and mount the vent cover on the outside of the sauna.



Use a 1 ½" (38mm) screw and attach the vent board on the inside of the sauna making sure it is tight but can still be turned.



The assembly of your Harvia M3 wood stove with chimney out the top is now complete.

Enjoy your sauna!

Manufactured by:



tel: 888-923-9813 | info@leisurecraft.com | web: www.leisurecraft.com